

### FERTILIZER SPREADER / SINGLE DISC 400 LT

Model	ZNTFS1-400	
Capacity	400	
Number of Discs	1	
Width	1060	
Length	1400	
Height	1200	
Weight	135	
Working Width	18	
Open/Close Adjustment	Mec/ Hyd	<b>agrozenit</b>
Stainless Steel Disc	optional	

### FERTILIZER SPREADER / SINGLE DISC 500 LT

Model	ZNTFS1-500	
Capacity	500	
Number of Discs	1	
Width	1060	
Length	1405	
Height	1230	
Weight	142	
Working Width	18	
Open/Close Adjustment	Mec/ Hyd	<b>agrozenit</b>
Stainless Steel Disc	optional	

### FERTILIZER SPREADER / SINGLE DISC 600 LT

Model	ZNTFS1-600	
Capacity	600	
Number of Discs	1	
Width	1120	
Length	1480	
Height	1230	
Weight	150	
Working Width	18	
Open/Close Adjustment	Mec/ Hyd	<b>agrozenit</b>
Stainless Steel Disc	optional	

### FERTILIZER SPREADER / SINGLE DISC 800 LT

Model	ZNTFS1-800	
Capacity	800	
Number of Discs	1	
Width	1120	
Length	1480	
Height	1320	
Weight	158	
Working Width	18	
Open/Close Adjustment	Mec/ Hyd	<b>agrozenit</b>
Stainless Steel Disc	optional	

### FERTILIZER SPREADER / DOUBLE DISC 600 LT

Model	ZNTFS2-600	
Capacity	600	
Number of Discs	2	
Width	1500	
Length	1195	
Height	1195	
Weight	190	
Working Width	18	
Open/Close Adjustment	Mec/ Hyd	<b>agrozenit</b>
Stainless Steel Disc	optional	

### FERTILIZER SPREADER / DOUBLE DISC 800 LT

Model	ZNTFS2-800	
Capacity	800	
Number of Discs	2	
Width	1505	
Length	1200	
Height	1200	
Weight	200	
Working Width	18	
Open/Close Adjustment	Mec/ Hyd	<b>agrozenit</b>
Stainless Steel Disc	optional	

### FERTILIZER SPREADER / DOUBLE DISC 1000 LT

Model	ZNTFS2-1000	
Capacity	1000	
Number of Discs	2	
Width	1800	
Length	1090	
Height	1090	
Weight	217	
Working Width	18	
Open/Close Adjustment	Mec/ Hyd	<b>agrozenit</b>
Stainless Steel Disc	optional	

### FERTILIZER SPREADER / DOUBLE DISC 1200 LT

Model	ZNTFS2-1200	
Capacity	1200	
Number of Discs	2	
Width	2350	
Length	1500	
Height	1810	
Weight	435	
Working Width	18	
Open/Close Adjustment	Mec/ Hyd	<b>agrozenit</b>
Stainless Steel Disc	optional	